

Make & Model	Type	Years	Bulk w/o Quick Plug	Pkg. w/o Quick Plug	Bulk Quick Plug#	Pkg. Quick Plug#	Install Time	Harness Location
			New#	New#	New#	New#		
<b>BUICK</b>								
Enclave		08-12	51420	51421	51422	51423	5	BH1
<b>CADILLAC</b>								
Escalade		14-15	-	-	51451	51452	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
		2002	51340	51341	51342	51343	5	BH3
<b>CHEVROLET/GMC</b>								
Acadia		07-15	51420	51421	51422	51423	5	BH1
Avalanche		03-06	51350	51351	51352	51353	5	BH3
		2002	51340	51341	51342	51343	5	BH3
Silverado/Sierra		14-15	-	-	51451	51452	5	BH1
	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.					
	Classic Body	2007	51350	51351	51352	51353	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
		99-02	51340	51341	51342	51343	5	BH3
		2015	51350	51351	51451	51452	5	BH3
		03-06	51350	51351	51352	51353	5	BH3
Tahoe		00-02	51340	51341	51342	51343	5	BH3
	New Body w/Amber Turn Signals	03-06	51350	51351	51352	51353	5	BH3
Suburban, Yukon		00-02	51340	51341	51342	51343	5	BH3
Yukon XL & Denali	New Body w/Amber Turn Signals	09-16	51420	51421	51422	51423	5	BH3
Traverse	w/Factory Tow Package							
<b>CHRYSLER</b>								
Aspen	w/Factory Tow Package	07-09	51330	51331	51332	51333	5	BH1
<b>DODGE/RAM</b>								
Dakota	w/Factory Tow Package	97-11	51330	51331	51332	51333	5	BH1
Durango	w/Factory Tow Package	11-15	51444	51445	51446	51447	5	BH8
		98-09	51330	51331	51332	51333	5	BH1
Ram 1500		13-14	-	-	-	51453	10	BH8
		2015	-	-	51438	51439	5	BH8
		10-12	-	-	51438	51439	5	BH8
Ram 2500		13-14	-	-	-	51453	10	BH8
		10-12	-	-	51438	51439	5	BH8
Ram 3500		13-14	-	-	-	51453	10	BH8
		10-12	-	-	51438	51439	5	BH8
Ram Pickup	All Full Size Pickups	95-09	51330	51331	51332	51333	5	BH1
<b>FORD</b>								
Bronco	Full Size	94-96	51320	51321	51322	51323	5	BH2
		92-93	51310	51311	51312	51313	5	BH1
Econoline Van		09-14	51430	51431	51432	51433	5	BH5
		92-08	51320	51321	51322	51323	5	BH1
Excursion		00-05	51320	51321	51322	51323	5	BH2
Expedition		13-14	51430	51431	51432	51433	5	BH5
		97-12	51320	51321	51322	51323	5	BH2
Explorer	w/Factory Tow Package	02-11	51320	51321	51322	51323	5	BH2
F-150		09-15	51434	51435	51436	51437	5	BH7
	New Body	04-08	51320	51321	51322	51323	5	BH2
	Heritage Edition	2004	51320	51321	51322	51323	5	BH2
F-150 & F-250 Light Duty		94-03	51320	51321	51322	51323	5	BH2
F-250 & F-350 Super Duty		08-16	51430	51431	51432	51433	5	BH5
		05-07	51370	51371	51372	51373	5	BH4
		99-04	51320	51321	51322	51323	5	BH2
F-250 & F-350 Heavy Duty		1997	51320	51321	51322	51323	5	BH2
F-150, F-250, F-350		94-96	51320	51321	51322	51323	5	BH2
F-Series Full Size Truck		92-93	51310	51311	51312	51313	5	BH1
F-450 & F-550 Super Duty		08-14	51430	51431	51432	51433	5	BH5
		05-07	51370	51371	51372	51373	5	BH4
Flex	w/Factory Tow Package	12-13	51434	51435	51436	51437	5	BH7
		09-11	51320	51321	51322	51323	5	BH2
Windstar	w/Factory Tow Package	95-03	51320	51321	51322	51323	5	BH2
<b>HONDA</b>								
Pilot		09-16	51390	51391	51392	51393	5	BH1
Ridgeline	w/Factory Tow Package	06-14	51390	51391	51392	51393	5	BH1
<b>HUMMER</b>								
H2		03-07	51350	51351	51352	51353	5	BH3
<b>INFINITI</b>								
QX56		04-13	51380	51381	51382	51383	5	BH1
<b>JEEP</b>								
Grand Cherokee	w/Factory Tow Package	11-15	51444	51445	51446	51447	5	BH8
<b>KIA</b>								
Borrego		09-11	51440	51441	51442	51443	5	BH1
<b>LAND ROVER</b>								
LR3		05-09	51320	51321	51322	51323	5	BH2
LR4		10-14	51320	51321	51322	51323	5	BH2
Range Rover	Including Sport	05-15	51320	51321	51322	51323	5	BH2
Range Rover Evoque		12-14	51320	51321	51322	51323	5	BH2
<b>LEXUS</b>								
GX460		10-12	51360	51361	51362	51363	5	BH1
GX470		03-11	51360	51361	51362	51363	5	BH1
LX470		03-07	51360	51361	51362	51363	5	BH1
LX570		2013	51360	51361	51362	51363	5	BH1
		08-11	51360	51361	51362	51363	5	BH1
<b>LINCOLN</b>								
Mark LT		06-08	51320	51321	51322	51323	5	BH2
MKT	w/Factory Tow Package	12-15	51434	51435	51436	51437	5	BH7
		10-11	51320	51321	51322	51323	5	BH2
Navigator		13-14	51430	51431	51432	51433	5	BH5
		98-12	51320	51321	51322	51323	5	BH2
<b>MERCURY</b>								
Mountaineer	w/Factory Tow Package	02-10	51320	51321	51322	51323	5	BH2
<b>NISSAN</b>								
Armada		04-15	51380	51381	51382	51383	5	BH1
Frontier		05-15	51380	51381	51382	51383	5	BH1
Pathfinder		05-15	51380	51381	51382	51383	5	BH1
Titan		04-15	51380	51381	51382	51383	5	BH1
Xterra		05-15	51380	51381	51382	51383	5	BH1
<b>SATURN</b>								
Outlook		07-09	51420	51421	51422	51423	5	BH1
<b>TOYOTA</b>								
4Runner		03-15	51360	51361	51362	51363	5	BH1
Land Cruiser		13-14	51360	51361	51362	51363	5	BH1
		03-11	51360	51361	51362	51363	5	BH1
Sequoia		03-14	51360	51361	51362	51363	5	BH1
Tacoma		07-15	51360	51361	51362	51363	5	BH1
Tundra		2015	-	-	51455	51456	5	BH4
		03-14	51360	51361	51362	51363	5	BH1

**Harness Location Designators:**  
 BH1 = Underneath dash, left of steering column, near emergency brake pedal  
 BH2 = Underneath dash, near center console  
 BH3 = Underneath dash, in junction box left of steering column  
 BH4 = Behind storage pocket, above ashtray  
 BH5 = Underneath dash, behind center access panel on passenger side  
 BH6 = Underneath dash, near brake pedal  
 BH7 = Behind storage pocket in center of dash  
 BH8 = Underneath dash, to right of emergency brake pedal